

Rural Tapping Saddle Installation Instructions



1. Insert the rubber seal into the saddle top by aligning the lug on the outside of the seal with the slot in the saddle.



2. Insert the bolts into the saddle bottom and push firmly into the hex recess.



3. Assemble the saddle halves in the desired location on the Rural poly pipe.



4. Thread each nut onto the bolt until firm and then complete tightening with a spanner.



5. Drill a hole using the correctly sized drill bit taking care not to damage the seal or thread.



6. Connect the desired threaded fitting to the outlet using PTFE tape.

NOTE: Following installation, the line should be thoroughly flushed to remove any swarf created from drilling the holes



The connection you can trust.